

Part	Description	
AAM American Automatrix PUP Driver for Jace 2	AAM American Automatrix PUP Driver - supports Niagara Slide scheduling and with Learn Discover function.	DR-IS-APUP-AX-J2
AAM American Automatrix PUP Driver for Jace 6	AAM American Automatrix PUP Driver - supports Niagara Slide scheduling and with Learn Discover function.	DR-IS-APUP-AX-J6
AAM American Automatrix PUP Driver for Jace 7	AAM American Automatrix PUP Driver - supports Niagara Slide scheduling and with Learn Discover function.	DR-IS-APUP-AX-J7
AAM American Automatrix PUP Driver for WS	AAM American Automatrix PUP Driver - supports Niagara Slide scheduling and with Learn Discover function.	DR-IS-APUP-AX-WS
Alarm Console, Enhanced Features	Supports Multi group and multi workstation, Multiple Client, up to 20 Client per station. 5x Client Station License comes free when purchased. Ability to acknowledge and delete alarms by individual instead of Admin Passwords only. Export of History Alarm, Monitoring of Alarms without the need to Logon, User Auto Log off if left unattended. Ability to have Pop up alarm at Workstation level. Ability to handle huge inflow of Alarm at the same time Ability to have a separate / Enterprise level Server. No need to reside on the same AX Supervisor PC.	DR-IS-ALMCSL-AX
Alarm Console, Additional Clients	Additional Alarm Console Clients Station License.	DR-IS-ALMCSL-CL
Allen Bradley CSPV4 Driver for Jace 2	Allen Bradley CSPV4 TCP Driver	DR-IS-CSPV4-AX-J2
Allen Bradley CSPV4 Driver for Jace 6	Allen Bradley CSPV4 TCP Driver	DR-IS-CSPV4-AX-J6
Allen Bradley CSPV4 Driver for Jace 7	Allen Bradley CSPV4 TCP Driver	DR-IS-CSPV4-AX-J7
Allen Bradley CSPV4 Driver for WS	Allen Bradley CSPV4 TCP Driver. Work With S-AX / S-AX-SBS. Without points limitation.	DR-IS-CSPV4-AX-WS
Allen Bradley CIP Driver for Jace 2	Allen Bradley CIP Driver	DR-IS-CIP-AX-J2
Allen Bradley CIP Driver for Jace 6	Allen Bradley CIP Driver	DR-IS-CIP-AX-J6
Allen Bradley CIP Driver for Jace 7	Allen Bradley CIP Driver	DR-IS-CIP-AX-J7
ASI Driver for Jace 2	ASI Controller's Driver	DR-IS-ASI-AX-J2
ASI Driver for Jace 6	ASI Controller's Driver	DR-IS-ASI-AX-J6
ASI Driver for Jace 7	ASI Controller's Driver	DR-IS-ASI-AX-J7
Barber Colman ASD Driver for Jace 2	Barber Colman ASD driver for PEM, MZII, MNASDi and etc. Features Learn and discover functions.	DR-IS-ASD-AX-J2
Barber Colman ASD Driver for Jace 6	Barber Colman ASD driver for PEM, MZII, MNASDi and etc. Features Learn and discover functions.	DR-IS-ASD-AX-J6
Barber Colman ASD Driver for Jace 7	Barber Colman ASD driver for PEM, MZII, MNASDi and etc. Features Learn and discover functions.	DR-IS-ASD-AX-J7
Barber Colman ASD Driver for WS	Barber Colman ASD driver for PEM, MZII, MNASDi and etc. Features Learn and discover functions.	DR-IS-ASD-AX-WS
Barber Colman GCM Driver for Jace 2	Barber Colman GCM Driver. Able to perform Serial Tunneling.	DR-IS-GCM-AX-J2
Barber Colman GCM Driver for Jace 6	Barber Colman GCM Driver. Able to perform Serial Tunneling.	DR-IS-GCM-AX-J6
Barber Colman GCM Driver for Jace 7	Barber Colman GCM Driver. Able to perform Serial Tunneling.	DR-IS-GCM-AX-J7
Barber Colman GCM Driver for WS	Barber Colman GCM Driver. Able to perform Serial Tunneling and can work with S-AX and S-AX-SBS without point limitation.	DR-IS-GCM-AX-WS
Clipsal Cgate TCP Driver For JACE 2	Clipsal (now Schneider) Cgate TCP driver	DR-IS-CGATE-AX-J2
Clipsal Cgate TCP Driver for JACE 6	Clipsal (now Schneider) Cgate TCP driver	DR-IS-CGATE-AX-J6
Clipsal Cgate TCP Driver For JACE 7	Clipsal (now Schneider) Cgate TCP driver	DR-IS-CGATE-AX-J7
Clipsal Cgate TCP Driver for AX Supervisor	Clipsal (now Schneider) Cgate TCP driver. Works with S-AX/ S-AX-SBS - Without point limitation.	DR-IS-CGATE-AX-WS
Clipsal Cbus Driver for Jace 2	Clipsal (now Schneider) Cbus driver	DR-IS-CLCBUS-AX-J2
Clipsal Cbus Driver for Jace 6	Clipsal (now Schneider) Cbus driver	DR-IS-CLCBUS-AX-J6
Clipsal Cbus Driver for Jace 7	Clipsal (now Schneider) Cbus driver	DR-IS-CLCBUS-AX-J7
Clipsal Cbus Driver for WS	Clipsal (now Schneider) Cbus driver. Works with S-AX/ S-AX-SBS - Without point limitation.	DR-IS-CLCBUS-AX-WS
CSI Inet for JACE 2	Driver to connect to Legacy CSI TAC I/Net networks	DR-IS-INET-AX-J2
CSI Inet for JACE 6	Driver to connect to Legacy CSI TAC I/Net networks	DR-IS-INET-AX-J6

CSI Inet for JACE 7	Driver to connect to Legacy CSI TAC I/Net networks	DR-IS-INET-AX-J7
CSI Inet for SoftJACE/WS	Driver to connect to Legacy CSI TAC I/Net networks	DR-IS-INET-AX-WS
Honeywell Cbus Driver for Jace 2	Honeywell Cbus Driver.Connect direct to JACE RS485 port	DR-IS-CBUS-AX-J2
Honeywell Cbus Driver for Jace 6	Honeywell Cbus Driver.Connect direct to JACE RS485 port	DR-IS-CBUS-AX-J6
Honeywell Cbus Driver for Jace 7	Honeywell Cbus Driver.Connect direct to JACE RS485 port	DR-IS-CBUS-AX-J7
Honeywell Cbus Driver for AX Supervisor	Honeywell Cbus Driver.Connect direct to S-AX/ S-AX-SBS PC RS485 port. PC Required PCI Card for RS485 port to purchase separately.	DR-IS-CBUSAXS-AX
Honeywell Cbus Driver for AX Supervisor, additional 500 point block	Additional 500 point block for AX Supervisor Cbus Driver	DR-IS-CBUSAXS-500
Honeywell Cbus TCP Driver for Jace 2	Honeywell Cbus TCP Driver. Price includes 1 x EasyIO for 1 bus. The driver needs 1 x easyIO for each bus for 31 Cbus devices (Type 1, Type 2, Zone Manager etc)	DR-IS-CBUSTCP-AX-J2
Honeywell Cbus TCP Driver for Jace 6	Honeywell Cbus TCP Driver. Price includes 1 x EasyIO for 1 bus. The driver needs 1 x easyIO for each bus for 31 Cbus devices (Type 1, Type 2, Zone Manager etc)	DR-IS-CBUSTCP-AX-J6
Honeywell Cbus TCP Driver for Jace 7	Honeywell Cbus TCP Driver. Price includes 1 x EasyIO for 1 bus. The driver needs 1 x easyIO for each bus for 31 Cbus devices (Type 1, Type 2, Zone Manager etc)	DR-IS-CBUSTCP-AX-J7
Honeywell Cbus TCP Driver for AX Supervisor	AX Supervisor Cbus TCP Driver, includes license for 500 Cbus RS485 points. Able to learn and discover points, without a JACE, directly to the AX Supervisor. Honeywell Cbus Driver. Price includes 1 x EasyIO for 1 bus. The driver needs 1 x easyIO for each bus for 31 Cbus devices (Type 1, Type 2, Zone Manager etc)	DR-IS-CBUSTCPAXS-AX
Honeywell Cbus TCP Driver for AX Supervisor, additional 500 point block	Additional 500 point block for AX Supervisor Cbus TCP Driver	DR-IS-CBUSTCPAXS-500
Johnson N2 Open driver for Jace 2	Johnson N2 Open driver. With Learn and Discover functions.	DR-IS-N2-AX-J2
Johnson N2 Open driver for Jace 6	Johnson N2 Open driver. With Learn and Discover functions.	DR-IS-N2-AX-J6
Johnson N2 Open driver for Jace 7	Johnson N2 Open driver. With Learn and Discover functions.	DR-IS-N2-AX-J7
Johnson N2 Open driver for WS	Johnson N2 Open driver. With Learn and Discover functions.	DR-IS-N2-AX-WS
Johnson N2 Slave Driver for Jace 2	Johnson N2 Slave Driver. Able to convert JACE to become part of Johnson VND device.	DR-IS-N2Slave-AX-J2
Johnson N2 Slave Driver for Jace 6	Johnson N2 Slave Driver. Able to convert JACE to become part of Johnson VND device.	DR-IS-N2Slave-AX-J6
Johnson N2 Slave Driver for Jace 7	Johnson N2 Slave Driver. Able to convert JACE to become part of Johnson VND device.	DR-IS-N2Slave-AX-J7
Modbus Driver for Jace 2	Modbus driver. Able to handle both TCP and RTU both in 1 driver. Both can run at the same time too. Able to discover the Device ID of the online controller. Work best with EasyIO 30P Modbus and EasyIO 30P Sedona Controllers.	DR-IS-MDB-AX-J2
Modbus Driver for Jace 6	Modbus driver. Able to handle both TCP and RTU both in 1 driver. Both can run at the same time too. Able to discover the Device ID of the online controller. Work best with EasyIO 30P Modbus and EasyIO 30P Sedona Controllers.	DR-IS-MDB-AX-J6
Modbus Driver for Jace 7	Modbus driver. Able to handle both TCP and RTU both in 1 driver. Both can run at the same time too. Able to discover the Device ID of the online controller. Work best with EasyIO 30P Modbus and EasyIO 30P Sedona Controllers.	DR-IS-MDB-AX-J7
Modbus Driver for AX Supervisor	Modbus driver –Able to handle both TCP and RTU both in 1 driver. Both can run at the same time, too. Able to discover the Device ID of the online controller. Works best with EasyIO 30P Modbus and EasyIO 30P Sedona Controllers. Can work with S-AX and S-AX-SBS without point limitation.	DR-IS-MDB-WS
Obix Client Driver for Jace 2	Niagara AX Obix Client Driver	DR-IS-OBIXCLT-AX-J2
Obix Client Driver for Jace 6	Niagara AX Obix Client Driver	DR-IS-OBIXCLT-AX-J6
Obix Client Driver for Jace 7	Niagara AX Obix Client Driver	DR-IS-OBIXCLT-AX-J7
Robertshaw Microsmart Driver for Jace 2	Robertshaw Microsmart driver. For Version 9.4C and above. With Learn and Discover functions.	DR-IS-MS-AX-J2
Robertshaw Microsmart Driver for Jace 6	Robertshaw Microsmart driver. For Version 9.4C and above. With Learn and Discover functions.	DR-IS-MS-AX-J6

Robertshaw Microsmart Driver for Jace 7	Robertshaw Microsmart driver. For Version 9.4C and above. With Learn and Discover functions.	DR-IS-MS-AX-J7
Robertshaw DMS Driver for Jace 2	Robertshaw DMS Driver	DR-IS-DMS-AX-J2
Robertshaw DMS Driver for Jace 6	Robertshaw DMS Driver	DR-IS-DMS-AX-J6
Robertshaw DMS Driver for Jace for Jace 7	Robertshaw DMS Driver	DR-IS-DMS-AX-J7
Siemens Apogee 600 TEC UC Driver for Jace 2	Siemens Apogee 600 TEC UC Driver. Connects directly to RS485 FLN devices.	DR-IS-TEC-AX-J2
Siemens Apogee 600 TEC UC Driver for Jace 6	Siemens Apogee 600 TEC UC Driver. Connects directly to RS485 FLN devices.	DR-IS-TEC-AX-J6
Siemens Apogee 600 TEC UC Driver for Jace 7	Siemens Apogee 600 TEC UC Driver. Connects directly to RS485 FLN devices.	DR-IS-TEC-AX-J7
Sierra Raven Driver for Jace 2	Sierra Raven Driver for JACE 2	DR-IS-Raven-AX-J2
Sierra Raven Driver for Jace 6	Sierra Raven Driver for Jace 6	DR-IS-Raven-AX-J6
Sierra Raven Driver for WS	Sierra Raven Driver for Web Supervisor	DR-IS-Raven-AX-WS
Steafa Smart 2 Driver for Jace 2	Steafa Smart 2 Driver, AETI-485 converter to purchase separately.	DR-IS-SM2-AX-J2
Steafa Smart 2 Driver for Jace 6	Steafa Smart 2 Driver, AETI-485 converter to purchase separately.	DR-IS-SM2-AX-J6
Steafa Smart 2 Driver for Jace 7	Steafa Smart 2 Driver, AETI-485 converter to purchase separately.	DR-IS-SM2-AX-J7
SMS Driver	SMS Driver that support Multigroup and Multimobile. Works with JACE and Web Supervisor. TC35I Compatible GSM module to purchase separately.	DR-IS-SMS-AX
Trane Comm3 Non Isolated Driver for Jace 2	Trane Comm3 Non Isolated driver	DR-IS-NICom3-AX-J2
Trane Comm3 Non Isolated Driver for Jace 6	Trane Comm3 Non Isolated driver	DR-IS-NICom3-AX-J6
Trane Comm3 Non Isolated Driver for Jace 7	Trane Comm3 Non Isolated driver	DR-IS-NICom3-AX-J7
Trane Comm4 Driver for Jace 2	Trane Comm4 driver	DR-IS-TComm4-AX-J2
Trane Comm4 Driver for Jace 6	Trane Comm4 driver	DR-IS-TComm4-AX-J6
Trane Comm4 Driver for Jace 7	Trane Comm4 driver	DR-IS-TComm4-AX-J7
Trend EINC Gateway Driver for Jace 2	Trend EINC Gateway TCP Driver. Able to learn and discover points.	DR-IS-EINC-AX-J2
Trend EINC Gateway Driver for Jace 2	Trend EINC Gateway TCP Driver. Able to learn and discover points.	DR-IS-EINC-AX-J6
Trend EINC Gateway Driver for Jace 2	Trend EINC Gateway TCP Driver. Able to learn and discover points.	DR-IS-EINC-AX-J7
Trend EINC Gateway Driver for AX Supervisor	AX Supervisor Trend EINC Driver, includes license for 500 Trend EINC Gateway points. Able to learn and discover points, without a JACE, directly to the AX Supervisor	DR-IS-EINC-AXS
Trend EINC Gateway Driver for AX Supervisor, additional 500 point block	Additional 500 point block for AX Supervisor Trend EINC Driver	DR-IS-EINC-500-AXS
Trend IQ2 Serial Driver for Jace 2	Trend IQ2 Serial Driver. Able to learn and discover points	DR-IS-IQ-AX-J2
Trend IQ2 Serial Driver for Jace 6	Trend IQ2 Serial Driver. Able to learn and discover points	DR-IS-IQ-AX-J6
Trend IQ2 Serial Driver for Jace 7	Trend IQ2 Serial Driver. Able to learn and discover points	DR-IS-IQ-AX-J7
Trend IQ3 TCP Driver for Jace 2	Trend IQ3 TCP Driver. Able to learn and discover points.	DR-IS-IQTCP-AX-J2
Trend IQ3 TCP Driver for Jace 6	Trend IQ3 TCP Driver. Able to learn and discover points.	DR-IS-IQTCP-AX-J6
Trend IQ3 TCP Driver for Jace 7	Trend IQ3 TCP Driver. Able to learn and discover points.	DR-IS-IQTCP-AX-J7
Trend IQ3 TCP Driver for AX Supervisor	AX Supervisor Trend IQ3 Driver, includes license for 500 Trend IQ3 TCP points. Able to learn and discover points, without a JACE, directly to the AX Supervisor	DR-IS-IQTCP-AXS
Trend IQ3 TCP Driver for AX Supervisor, additional 500 point block	Additional 500 point block for AX Supervisor Trend IQ3 Driver	DR-IS-IQTCP-500-AXS
VING Hotel Card Access	Server interface for Energy Management of smart Hotels	DR-IS-VING-AXS